

Did you copy a bunch of stuff to the SD card only to find it missing on the nookColor when you go to files?

You might have created multiple partitions on your SD memory card, and one of them is in a format that only your computer understands. The best thing to do when you have this problem is to format the SD card by following these steps:

THIS WILL DELETE YOUR SD CARD CONTENTS

1. Go to the Settings Menu and tap "Device Info"
2. Tap on SD Card
3. Tap on Unmount SD card
4. Tap the Format SD Card, the NOOKcolor displays a warning that formatting the memory card will erase its contents.