Yes. Connect your nook to your PC or Mac. It will show up like a USB memory stick on your computer. Find the folder named "My Wallpaper" and drag and drop your wallpaper image to that directory. Next go to the Settings menu to choose the wallpaper image to display.