

Warning: This will remove all your content and should be a last resort when your nook will not work properly. Use this reset procedure at your own risk.

There are a lot of "ideas" on how to do this. I think these are the two reliable ways.

Method #1. Use this if you haven't rooted your nook.

- Press Settings on the touch pad, then Device, then "*Unregister your Nook*"
- Below that press "*reset to factory settings*" & Confirm
- It should reboot and be restored to the latest firmware you have installed.

Method #2. Use this to go back to the firmware the nook was shipped with (use this if rooted)

This will actually restore it to the *same exact* way you got it from the store. It's the equivalent of restoring your computer with your installations disks.

- Turn off your nook by holding down the Power button.
- With it off, press and hold the power button until the screen flickers black for a moment THEN CONTINUE to hold it for another 15 seconds. You won't see anything happen at this point - but the animated arrows will stop typically.
- Repeat the above step 6 more times in a row. YES, Six is the magic number that tells the nook to do a restore.
- Now press the Power Button once to turn on the nook.
- The touch screen will go black with a description of what it's doing (restoring). This may take several minutes - do NOT stop it.
- To update to the latest software version, press the "My Library" button. While in the "My B&N Library" area tap "Check for new B&N content". It will get the new firmware and start updating the latest software. Again, this will take a while like above steps.